



# OPERATOR'S MANUAL

BVE SERIES  
Electric Motor / Diesel fired

## READ THIS MANUAL

This manual contains important information for the use and safe operation of your RAMTEQ® machine. **FAILURE TO READ THIS MANUAL AND FOLLOW ITS INSTRUCTIONS PRIOR TO OPERATING OR ATTEMPTING ANY SERVICE OR MAINTENANCE PROCEDURE COULD RESULT IN SERIOUS INJURY OR DEATH TO YOU OR OTHER PERSONS; ALSO DAMAGE TO THE MACHINE OR TO OTHER PROPERTY.**



## Table of Contents

### SECTION 1 OPERATOR'S MANUAL

■ UNPACKING.....	2
■ SAFETY INSTRUCTIONS AND WARNINGS.....	3
■ OPERATING INSTRUCTIONS.....	4
■ MAINTENANCE INSTRUCTIONS.....	5

### SECTION 2 PARTS AND SERVICE MANUAL

■ PARTS DIAGRAM.....	7
■ HOSE, WAND, & GUN.....	8
■ PUMPS.....	8
■ BURNER ASSEMBLY.....	9
■ CONTROL BOX ASSEMBLY.....	9
■ PLUMBING DIAGRAMS.....	10
■ WIRING DIAGRAMS.....	12
■ TROUBLESHOOTING.....	13
■ WARRANTY.....	14

## Unpacking Instructions

### INSPECTION

Carefully unpack your new RAMTEQ equipment by removing the banding and cardboard box from pallet. Remove the pressure washer from the pallet and check for any physical damages that may have occurred during shipment. Check for all parts specified and shown below.



#### INCLUDED PARTS

- Pallet
- Packing Material
- Outer Box
- BVE Series Machine
- Operator's Manual
- Wand / Trigger Gun
- Nozzles 0° 15° 25° 40°
- Hose 3/8" X 50'
- QC Hose Fittings

### NOTICE

Information in this operator's manual is subject to change without notice.

RAMTEQ SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN. This operator's manual contains information protected by copyright. No part of this operator's manual may be photocopied or reproduced in any form without prior written consent from RAMTEQ®.

© RAMTEQ®, 2005  
All rights reserved. Printed in USA.



## Safety Guidelines



**READ THIS FIRST! FAILURE TO READ AND OBSERVE ALL WARNING STATEMENTS COULD RESULT IN SEVERE BODILY INJURY OR DEATH, POSSIBLE INJURY TO OTHER PERSONS, DAMAGE TO MACHINE OR OTHER PROPERTY.**

- DO NOT operate this machine in areas where open flames are not permitted. DO NOT store or use combustible materials on or near this machine. Use this equipment only in well ventilated areas. Failure to follow this warning may cause carbon monoxide build up, fire or explosion, and possible injury or death.
- DO NOT operate this machine while under the influence of alcohol, drugs or while fatigued.
- DO NOT direct discharge stream at yourself or others. Risk of injection or injury may occur. Never put your hand or fingers over the spray tip. Do not try to stop or deflect leaks with your hand or body. Always face nozzle and wand to the ground when testing.
- DO NOT operate this machine WITHOUT wearing protective Eye Wear. Gloves, Hard Hat, Mask, Ear Plugs & Steel Toe Work Boots are also recommended, DO NOT wear loose clothing. Keep your body and clothing clear of the engine and discharge stream when the machine is running.
- DO NOT tie back or block trigger gun in OPEN position. Never leave the pressure washer unattended once you have started it. If you leave, shut down machine completely.
- DO NOT overreach or stand on an unstable support while operating this machine. Maintain good footing and balance.
- DO NOT permit this machine to run while unattended or for extended periods of time with trigger gun closed. Damage to pump may occur.
- DO NOT operate this machine in an unsafe manner or around unsupervised children. Keep all other personnel clear while operating this machine. This product should only be operated by trained personnel.
- DO NOT alter original factory settings prior to operating this machine. Risk of injury to yourself or other persons may occur.
- DO NOT remove hoses, guns, nozzles or any components while this machine is still hot or while it is running.
- DO NOT attempt to service this machine before reading the service manual.
- DO NOT use water with a temperature over 140 degrees Fahrenheit
- DO NOT use any electrical outlet that is not properly grounded or does not comply with all federal, state, and local laws and/or electrical codes
- DO NOT put diesel fuel in to a gasoline tank or gasoline into a diesel tank. Observe correct markings on fuel tanks before filling.
- DO NOT operate this machine without knowing how to stop and bleed water pressures. Know all controls before using this machine.
- DO NOT spray caustic, acids or abrasive fluids through this machine.
- DO NOT permit water to freeze inside this machine. Pump and plumbing damage may occur.
- Use only recommended RAMTEQ parts when servicing this machine.
- RAMTEQ will not be held liable for any unauthorized modifications made to this machine. Any such action will void the warranty.



## Operating Instructions

### LOCATION GUIDELINES

- Locate the machine on a solid and level surface so that engine and pump crankcase oil lubricate components properly. Avoid areas where water can build up in the working area. Possible injury can occur caused by the surface becoming slippery from water build up.
- Locate the machine in a well-ventilated area and away from flammable materials or fumes. Be sure ventilation warnings are observed. Keep pressure washer at least 18" away from flammable materials.
- Locate the machine so the operator has easy access to the pressure washer and its controls. Locate the machine so that it is protected from external damage.
- To prevent damage and excessive hose wear, locate the pressure washer so that the hose does not cross traffic areas

### STARTING THE MACHINE

Following the steps below will insure successful operation:

- Read this manual completely before attempting to start the machine.
- Check that the Motor/Burner switches are in the "OFF" position
- Check the diesel tank and fill with a good grade of diesel fuel #1, #2 or kerosene.
- Check the pump oil level and fill with SAE 30w *non-detergent* oil if needed.
- Connect water hose to pump (or float tank if equipped). Turn on water source.
- Connect the power cord to a properly grounded power source.
- Attach high pressure hose to base of spray gun.
- Install water nozzle at the end of wand, making sure it is clear of any obstructions.
- Turn pump switch to "ON"
- Pull trigger on gun until a steady stream of water comes out the nozzle. This purges any air in the system.
- Check for leaks in the system and cycle trigger gun to insure bypass is adjusted correctly. Repair any leaks and correct unloader adjustment if needed. Turn off machine before attempting any repairs.
- Turn burner switch to "ON". Check for burner ignition.
- Adjust thermostat to desired temperature appropriate to the task. Maximum temperature setting may not be needed.
- Insert detergent siphoning tube into a DOT approved container and open the metering valve for detergent application.

### WASHING TECHNIQUES

- Washing from bottom up increases dwell time of soap and lessens vertical streaks.
- Turn soap metering valve "OFF" to purge system of soap
- Rinsing with cold water from top down will retard detergent reaction which will enhance the rinsing performance.
- Wash at 30 to 60 degree angles to prevent splashback.

### STOPPING THE MACHINE

- Turn burner switch to "OFF". Allow water to discharge for a few minutes while cooling down.
- Turn pump switch to "OFF".
- Disconnect water source.
- Pull gun trigger to release water pressure from system.
- Disconnect wand & gun assembly.
- Wind up pressure hose on hose reel.



## Maintenance Instructions

### MAINTENANCE PRECAUTIONS

- Do not permit acidic, caustic or abrasive fluids to be pumped through system.
- Periodically clean detergent inlet screen. This will ensure proper flow of water to the pump.
- High mineral content in water may adversely affect your machine and may require the use of a water softener to ensure proper operation.
- NEVER run the pump dry under any circumstances. Doing so will cause extreme damage to the pump.



**FAILURE TO MAINTAIN HEAT EXCHANGER COIL MAY RESULT IN A STEAM EXPLOSION WHICH MAY CAUSE SERIOUS INJURY OR DEATH.**

### HEAT EXCHANGER COIL MAINTENANCE

- Hard water conditions may eventually cause clogging in the heat exchanger coil if left unattended. Scale deposits will compromise the heating efficiency and produce an unsafe condition over time. It may be necessary to descale coil.
- Scale buildup from certain detergents may eventually clog up the heat exchanger coil causing an unsafe condition. Use only recommended detergents for better cleaning efficiency.
- Black carbon deposits that collect on the outside wall of the heat exchanger coil may be a result of using a poor grade of fuel or improper burner operation. Heating fuel should be void of water and sediments to eliminate the possibility of sooting and compromising the efficiency of the coil.

### MOVING, STORAGE

- Place machine in covered area when not in use to protect from elements. Protect machine from freezing in cold temperatures by storing in a heated location.

### WINTERIZING

- Non-float Tank Machines: To protect the machine from freezing temperatures while storing or transporting, connect short length of garden hose (approximately 3 ft.) to water inlet connection on machine. Remove the pressure nozzle from the wand and insert the short garden hose end into a container of antifreeze. Place the wand into the antifreeze container and start engine running machine until antifreeze appears from the end of the wand. Turn engine "OFF" and replace pressure nozzle. Coil up hose and move machine to storage area.
- Float Tank Machines: Pour antifreeze into float tank and remove water nozzle from end of wand and carefully insert into opening of float tank. Start machine and run until antifreeze water mixture has circulated throughout the machine returning back to the float tank.

### PUMP MAINTENANCE


- Fill crankcase to dot on oil gauge window per specifications with the specific oil created by the pump manufacturer (i.e. **General Pump Oil**). Ensure the right oil for specific pump as it may vary.
- Change oil after **40 Hour Break-in Period**.
- Change oil every **Three Months or at 500 Hour Intervals** thereafter.



## Maintenance Instructions

### ELECTRODE SETTINGS

■ Inspection of all wires, spring contacts and electrodes should be done periodically.




**IF BLACK OR WHITE SMOKE VENTS FROM EXHAUST PORT UPON STARTING EQUIPMENT, DISCONTINUE USE AND ADJUST AIR BANDS BEFORE RESTARTING.**

### OIL BURNER AIR BAND ADJUSTMENT

RAMTEQ® sets oil burners at sea level. Air bands may need adjustment at higher elevations to offer enhanced performance of the burner and extended life of the machine.


■ Adjustment of burner is done with pump motor and thermostat set to maximum. Loosen locking screw on air band, then close band until black smoke vents up exhaust vent. Take careful note of air band position when black smoke is first noticed. Slowly open air band until white smoke vents, then turn air band halfway back to where black smoke was first noted. Tighten air band locking screw. When properly set, the unit should NOT have either "black" smoke or "white" smoke during operation.




### UNLOADER ADJUSTMENT

■ All RAMTEQ machines have the unloader correctly set at the the factory. Setting an unloader is a difficult job without the proper equipment and training. Should the need arise to change the unloader settings, please contact your local distributor.

**Sutner Unloader**




**CHANGING THE UNLOADER SETTINGS WITHOUT THE PROPER EQUIPMENT AND TRAINING MAY RESULT IN NON-WARRANTY DAMAGE TO THE PUMP.**

**BVE Parts Diagram**

Ref. #	Part #	Description	Qty.
1	190-00002-01	Fuel Tank, 9 gallon green	1
2	140-00001-01	Cap, Fuel Gauge, Diesel, Black	1
3a	200-00009-01	Motor, 5hp 208/230/1 Baldor L1410T	1
3b	200-00005-01	Motor, 5hp 208/230/3 Baldor M3218T	1
3c	200-00012-01	Motor, 6hp 208/230/1 Baldor	1
3d	200-00010-01	Motor, 7.5hp 208/230/1 Baldor L1510T	1
3e	200-00006-01	Motor, 7.5hp 208/230/3 Baldor M3311T	1
3f	200-00007-01	Motor, 10hp 230/460/3 Baldor M3313T	1
4	180-00008-01	Chassis, BV Series	1
	170-00002-01	Wheel, Caster Swivel, 6"	2
	170-00004-01	Wheel, Caster Swivel, 8"	2
	180-00052-01	Bracket, four wheel configuration	2
5	170-00003-01	Wheel, pneumatic split rim	2
6	516-00001-01	Bushing, wheel collar, 5/8"	2/4
7	175-00001-02	Axle, two and four wheel configuration	1/2
	567-00016-01	Washer, Wheel Plastic	2/4
8a	250-00004-01	Burner, Assembly 208/230/1	1
8b	250-00001-01	Burner, Assembly 460/3	1
9	180-00007-01	Plate, Burner	1
10	055-00029-01	Float Tank Assembly	1
11	180-00009-01	Handle	1
	180-00038-01	Wand, Box	1
	567-00015-01	Grommet, Rubber Wand Holder, 2"	1
12	180-00020-01	Shell, SS Removable, 18" X 23"H	1
	191-00006-01	Insulation, Blanket 1" x 24"w, 4#	1
13	180-00072-01	Cap, Coil Large	1
14	191-00004-01	Insulation, Cap, 18" x 10"	1
15	155-00003-01	Coil, Large, Diesel Fired	1
16	180-00021-01	Shell, SS Stationary, 18" X 23"H	1
17	180-00063-01	Belt Guard, Enclosure	1
18	180-00062-01	Belt Guard	1
19a	220-00004-01	Pump, General T1011-R (BVE 500,600)	1
19b	220-00009-01	Pump, General TS2021-R (BVE 750,1000)	1
	180-00051-01	Bracket, Pump Belt Tension Stationary	1
20	180-00006-01	Plate, Power	1
	567-00001-01	Grommet, Nozzle Holder	4
	584-00003-11	Pulley, 2BK50H (BVE 500,600)	1
	584-00002-09	Pulley, 2BK80H (BVE 500,600)	1
	586-00004-04	Belt, BX36 (BVE 500,600)	2
	516-00002-03	Bushing, SP Split Taper, H 1-1/8" (BVE 500,600)	1
	516-00002-01	Bushing, SP Split Taper, H-24mm (BVE 500,600,750,1000)	1
	584-00002-08	Pulley, 2BK45H (BVE 750)	1
	584-00002-09	Pulley, 2BK80H (BVE 750)	1
	586-00004-04	Belt, BX36 (BVE 750)	2
	516-00002-04	Bushing, SP Split Taper, H 1-3/8" (BVE 500,750,1000)	1
	584-00002-04	Pulley, 2BK57H (BVE 1000)	1
	584-00002-06	Pulley, 2BK70H (BVE 1000)	1
	586-00004-04	Belt, BX36 (BVE 1000)	2




**Hose, Wand & Gun**

Ref.#	Part #	Description	Qty.
1a	270-00028-01	Nozzle, Water #5.5 0° (BVE 500,600)	1
1b	270-00028-02	Nozzle, Water #5.5 15°(BVE 500,600)	1
1c	270-00028-03	Nozzle, Water #5.5 25°(BVE 500,600)	1
1d	270-00028-04	Nozzle, Water #5.5 40°(BVE 500,600)	1
1e	270-00025-01	Nozzle, Water #4.0 0° (BVE 750)	1
1f	270-00025-02	Nozzle, Water #4.0 15°(BVE 750)	1
1g	270-00025-03	Nozzle, Water #4.0 25°(BVE 750)	1
1h	270-00025-04	Nozzle, Water #4.0 40°(BVE 750)	1
1i	270-00028-01	Nozzle, Water #5.5 0° (BVE 1000)	1
1j	270-00028-02	Nozzle, Water #5.5 15°(BVE 1000)	1
1k	270-00028-03	Nozzle, Water #5.5 25°(BVE 1000)	1
1m	270-00028-04	Nozzle, Water #5.5 40°(BVE 1000)	1
2	265-00001-01	36" Wand, Insulated	1
3	275-00001-01	ST1500 Trigger Gun	1
4	552-00004-03	3/8" Quick Connect, Female Plug	1
5	284-00001-01	Hose 3/8" X 50" R-1 Swivel Ends	1

**BVE Belt Drive Pump**

General Pump T1011-R, T2011-R, TS2021-R Triplex Plunger Pump




Ref.#	Part #	Description	Qty.
1	220-00004-01	T1011 Triplex Plunger Pump Complete (BVE 500,600)	1
1a	220-00009-01	TS2021 Triplex Plunger Pump Complete (BVE 1000)	1
2	221-00001-06	Manifold, Brass Head T1011 (BVE 500,600)	1
2a	221-00001-02	Manifold, nickle plated Head TS2021 (BVE 750, 1000)	1

**Pump Repair Kits**

Part #	Description	Qty.
221-00002-01	Check Valve Assembly Kit #1 (All BVE Series)	6
221-00018-01	Oil Seal Kit #2 (All BVE Series)	3
221-00019-01	Oil Ring and Valve Cap Kit # 4 (T1011)	6
221-00026-01	Oil Ring and Valve Cap Kit #5 (T2011)	6
221-00010-01	Head Packing Complete Kit #28 (All BVE Series)	1




**BVE Burner Assembly**

Ref.#	Part #	Description	Qty
1	251-00001-01	Fuel Pump w/ Solenoid 115v	1
2	256-00001-02	Main Burner Gasket	1
3	245-00012-16	Nozzle	1
4	258-00002-02	Electrode Pair	1 pr
5	252-00001-03	Transformer 115v	1
5a	252-00001-02	Transformer 208/230v	1
6	253-00001-02	Coupling	1
7	253-00002-02	Fan Wheel 6.25"x4.0"	1
8	254-00001-03	Motor 115v/60/1	1
8a	254-00001-02	Motor 208/230v/60/1	1
9	577-00003-01	Filter, Fuel Inline Racor	1
	578-00001-01	Element, Fuel Filter, Racor	1
	280-00003-01	Hose, Inlet/Outlet Fuel Line (not shown)	2
	556-00001-01	Clamp, Hose (not shown)	2

**Burner Assembly Complete**


250-00007-01	EH-V-115	(BVE 500, 750, 1000)
250-00004-01	EH-V-230	(BVE 500, 600, 750, 1000)

**BVE Control Box Assemblies**


Ref.#	Part #	Description	Qty.
1	180-00027-01	Control Box Panel	1
2	180-00150-01	Control Box	1
3	305-00006-01	Label,Control Box Small	1
4	571-00002-01	Hour Meter	1
5	450-00001-01	Pump/Burner Switch On/Off	2
6	573-00001-01	Thermostat Assembly	1
7	505-00001-01	1/4 -20 Bolt	2
8	508-00002-02	Tinnerman	2




## BVE 500, 600 Base Plumbing




## BVE 500, 600 Upgrade Plumbing




## BVE 750, 1000 Base Plumbing




## BVE 750, 1000 Upgrade Plumbing



**BVE Wiring Diagrams**

## BVE Wiring Diagrams




# ELECTRICAL SCHEMATIC BVE, XVE UPGRADE

**230 VOLT  
1Ph UNITS**

**Wiring Effective:  
9/27/2005**




## BVE Wiring Diagrams





## BVE Wiring Diagrams




**ELECTRICAL SCHEMATIC  
BVE, XVE  
UPGRADE**


**230 VOLT  
3Ph UNITS**

**Wiring Effective:  
10/13/2004**



## BVE Wiring Diagrams



**BVE Wiring Diagrams****ELECTRICAL SCHEMATIC  
BVE, XVE  
UPGRADE****460 VOLT  
3Ph UNITS****Wiring Effective:  
2/22/2006**



## Troubleshooting

problem	cause	action
Low Water Pressure	Insufficient water source Old or incorrect nozzle Plumbing or hose leak Obstruction in spray nozzle Chemical valve open Unloader valve worn Pump valves dirty or worn	Check hose size/water source Replace nozzle Tighten, repair or replace leak Clean or replace nozzle Close valve or submerge hose Replace unloader Clean or replace packing/valves
No Chemical Flow	Detergent valve closed Low detergent level Chemical screen dirty	Open detergent valve Fill detergent container Clean detergent screen
Burner Not Igniting	No fuel Burner switch turned off Thermostat set too low Clogged fuel filter Defective pressure switch Clogged burner nozzle Fuel pump malfunction Improper electrode setting	Fill fuel tank with proper fuel Turn burner switch on Reset thermostat Replace fuel filter Replace pressure switch Replace burner nozzle Replace fuel pump Clean/reset to specifications
Excessive Burner Smoke	Improper fuel being used Water contamination in fuel Improper air band adjustment Low fuel pressure Air leaks in fuel lines Soot on coils/burner assembly Misaligned electrodes Dirty burner nozzle	Use Diesel #1/#2 or Kerosene Drain fuel and replace with new Readjust air band/altitude Adjust to specifications Check for air leaks or bubbles Clean coils/burner assembly Realign to specifications Clean or replace burner nozzle
Pressure Relief Valve Leaks	Nozzle is dirty Defective relief valve Unloader adjusted incorrectly Restriction on discharge hose Scale restricting flow in coil	Clean or replace nozzle Replace relief valve Adjust unloader valve Remove nozzle and flush line Clean coil
Pump Motor Not Running	Pump motor switch off GFCI tripped No voltage to machine Clogged water nozzle Insufficient voltage/ampereage	Turn on pump motor switch Reset and test GFCI Check power source Clean water nozzle Use proper drop cord
Pump Noisy	Air in suction line Pump valves dirty Check valve springs worn Low pump oil Pump bearings are worn Incoming water too hot	Check inlet water fittings Clean/replace pump valves Replace check valves Add SEA 30wt. non-detergent Replace/rebuild pump Reduce temperature/ambient
Water In Oil	High humidity environment Oil seal worn Plunger packing worn	Change oil frequently Check and replace oil seal Check and replace packing
Water Dripping/Pump	Plunger packing is worn Plunger retainer oil ring worn Cracked ceramics	Install new packing kit Replace oil ring Replace ceramics
Oil Dripping	Oil seal worn Cracked manifold	Check and replace oil seals Replace manifold
Fluctuating Pressure	Unloader not adjusted Valves worn Dirt or blockage in valves Pump sucking air Worn plunger packing	Adjust to specifications Replace with valve kit Clean or replace valve Check water/detergent supply Replace packing kit
Pump Head Overheating	Extended period in bypass	Pull trigger gun for water flow

## Limited One Year **WARRANTY**

Ramteq Incorporated ("RAMTEQ") warrants that the Product you have purchased from RAMTEQ or from an Authorized RAMTEQ Reseller is free from defects in materials or workmanship under normal use for a period of one (1) year from the date of purchase. This warranty extends only to you, the original Purchaser. It is not transferable to anyone who subsequently purchases the Products from you. This warranty specifically excludes expendable items, including but not limited to hoses, seals, nozzles and gunjets. RAMTEQ manufacturers warrant certain components of the Products for periods greater than one (1) year. MOTORS, GENERATORS, PUMPS, COILS, BURNERS AND ENGINES ARE WARRANTED BY THEIR RESPECTIVE MANUFACTURERS, AND SERVICED THROUGH THESE MANUFACTURERS' LOCAL AUTHORIZED SERVICE CENTERS. Specific warranty details can be found on the individual manufacturers website. RAMTEQ CANNOT PROVIDE WARRANTY ON THESE ITEMS.

During the warranty period, RAMTEQ will repair or replace defective parts, at the option of RAMTEQ.

This limited warranty does not extend to any Product not purchased from RAMTEQ or from an Authorized RAMTEQ Reseller. This limited warranty also does not extend to any Product that has been damaged or rendered defective (a) as a result of accident, misuse or abuse; (b) by operation outside the specifications in the intended applications; (c) by the use of parts not sold or manufactured by RAMTEQ; (d) by the modification of the Product.

### Warranty Disclaimer

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY, RAMTEQ MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RAMTEQ EXPRESSLY DISCLAIMS ALL AND ANY WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY HAVE BEEN IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS EXPRESS LIMITED WARRANTY.

### Limitation of Remedy

RAMTEQ IS NOT LIABLE FOR ANY DAMAGES CAUSED BY THE PRODUCT OR FAILURE OF THE PRODUCT TO PERFORM, INCLUDING INCIDENTAL AND CONSEQUENTIAL DAMAGES. THIS LIMITATION APPLIES WHETHER DAMAGES ARE SOUGHT, OR A CLAIM MADE, AS A CONTRACT CLAIM, AS A TORT CLAIM, OR ANY OTHER CLAIM.

THIS LIMITATION OF LIABILITY, HOWEVER, WILL NOT APPLY FOR PERSONAL INJURY.

### U.S.A. State Laws

Some states do not allow limitation on how long an implied warranty lasts. In such states, the limitations or exclusions of this Limited Warranty may not apply to you.

Some states do not allow the exclusion or limitation in incidental or consequential damages for consumer products. In such states, the exclusion may not apply to you. This limited warranty gives you specific legal rights. You may also have other rights that may vary from state to state. You are advised to consult applicable state laws for a full determination of your rights.

### How to Obtain Warranty Service

TO OBTAIN WARRANTY SERVICE YOU MUST CONTACT RAMTEQ or an AUTHORIZED RAMTEQ RESELLER.



## Manufacturers Warranty Period

Click on pictures to open manufacturers website.



5 years



5 years



3 years



3 years



3 years



18 months

M&M Manufacturing Co. Inc.

3 years



18/36 months



1 year